


How to setup your router



Please connect your router to the ONT (The ONT is often located in the hallway cupboard or under the stairs) using the ethernet cable provided (White or yellow cable included with your router). Please connect one end to LAN or LAN 1 on the ONT and the other end to the WAN port (left hand port) on your router.

Please then connect the power lead to your router and switch on, it will be ready for use in about 2 minutes.

Your router WiFi details can be found on the back of the router.

Enter these details into your wireless device to join the wireless network. If you require the WPS button, it is on the front of the router, briefly press the button once to activate.

If you would like to use the advanced functions of the router like parental controls, please connect your smart phone to the wireless network and download the TP-Link Aginet App.

Please sign in to the App with the admin details provided on the back of the router.

