


How to setup your router



Please connect your router to your ONT (The ONT is often located in the hallway cupboard or under the stairs) using the Ethernet Cable Provided (White cable included with your router). Please connect one end to LAN 1 on your ONT and the other to the WAN port (Top port) on your router.

Please then connect the power lead to your router and switch on, it will be ready for use in about 2 minutes.

Enclosed in the router box is your router WiFi details.

Enter these details into your wireless device to join the wireless network.

If you wish to connect a device using a wired connection please connect the device to Port 2 on the router (The bottom port).

If you would like to use the advanced functions of the router like parental control. Please connect your smart phone to the wireless network and download the TP-Link Deco app.

Please sign in to the App with the admin details provided in the router box.

